



No	Part No	Description	Qty	
1	MS-FM-100-R1	Back Door	R/L	
2	MS-FM-106-R3	Power Suply Base	1	
3	EA1013 & EA1015	Power Suply	2	
4	4A	MS-ASSY-19-R0	Main PCB Assy	1
	4B	BAFB66A	MPU Controler	1
	4C	BAFB151	Prize Door Drive Mega Stacker	1
	4D	BAFB526	Sound Board	1
	4E	BA1605	Ampli PCB	1
5	5A	MS-ASSY-20-R0	Woofer	1
	5B	EA1203	Speaker 6" Woofer	1
6	MS-ASSY-20-R0	Main Cabinet	1	
7	MS-FM-00-R0	Bracket Trafo	1	
8	MS-FM-105-R0	PCB Base Rail -2	R/L	
9	MS-FM-104-R0	PCB Base Rail -1	R/L	
10	MS-FM-09a-R0	Service Door Power Suply	1	
11	MS-FM-09-R1	Service Door PCB	1	
12	MS-SA-149-R0	Cash Box Assy	1	
13	MS-SA-150-R0	Housing Cash Box Assy	1	
14	MS-Assy-17-R1	Coin Door	1	
15	EA0284	Warning Rotari Lamp	R/L	
16	MS-FM-53-R1	Breket Lamp Warning	R/L	
17	17A	MS-SA-02-R0	Box Speaker Assy	R/L
	17B	MS-SA-122-R0	Casing Speaker Box Assy	R/L
	17C	EA1206	Speaker 4"	R/L

